

BPS 204-Client

The screenshot shows the BPS204 Client software window. On the left, there are labels for various controls: Pulse Level, Frequency, Pulse Polarity, Pulse Mode, Trigger Mode, Probe Trigger, Main Delay, Delta Delay, and Control. The software interface includes the following settings:

- Pulse Level:** 0200 V (slider from 50 to 1k)
- Frequency:** 00100.0Hz (slider from 0.1 to 10k)
- Pulse Polarity:** ☒ Positive, ☐ Negative
- Pulse Mode:** ☐ Single Pulse, ☒ Double Pulse
- Trigger Mode:** ☒ Free Running, ☐ Sync Single Trigger, ☐ Sync Double Trigger
- Probe:** ☐ Single Cable, ☐ Dual Cable
- Pulse Delays:**
 - Main Delay:** 000 steps
 - Delta Delay:** 040 steps
- Control:** Start Pulsing button
- Status:** Source: BPS204, Probe: ICI-DP HH500-15