

# SMA-SMA RA

Cable SMA-SMA, right angle



## Short description

The right-angle SMA-SMA cable is used to connect the ICR probe with the SMA measurement input on a Langer Scanner.