



## Short description

The Connection Board Control software is used to monitor and control the test IC. The test IC is connected to the PC via the Connection Board. The signals are transmitted to the Connection Board Control software via a USB cable and displayed in the user interface.

## Technical parameters

<b>Operating system</b>	Windows XP SP3 and above
<b>Interface</b>	USB
<b>HD space</b>	20 MB
<b>Processor</b>	Pentium III 500 MHz
<b>Memory</b>	128 MB